

# HySecurity SwingSmart DC

*Installation Instructions*

**American Gate Lock** PART NUMBER: **AGL-6**



1. Remove existing arm cover fastener. (Black star knob)



2. Thread on the American Gate Lock inner fastener.



3. Use supplied wrench to tighten inner fastener. (Clock-wise)



4. Place outer cylinder over inner fastener.



5. Install padlock through holes in outer cylinder.